

# Southern Screed

## Screed Surface Preparation

Preparation of the screed surface is advised only for areas which are going to be receiving an adhesive or glue.

**DRY IT**

**SAND IT**

**VACUUM IT**

**PRIME IT**

### Make sure the screed is dry

- Run dehumidifiers with the building sealed
- Run the Underfloor heating with the windows open
- Make sure the floor has had a complete heat cycle
- Let the floor cool back down fully

### Remove loose material

The laitance can be removed using a stiff broom the next day.

Sanding of any screed is recommended to remove any loose material including plaster

### Prime

Vacuum the floor and if required sand the floor.

Prime the floor using 1 coat of Acrylic primer